



5700 Elite Button Diagram (As of 1.49 firmware)

Blue Line: Up or Down Arrow
 Red Line: Left or Right Arrow
 Black Line: Select Button


Main Menu (Pressing Gear button)



System




About



Easy Mode (Sheet 2)



Easy mode is not found on non-LiNK models and 5700X models.

Blue Line: Up or Down Arrow
Red Line: Left or Right Arrow
Black Line: Select Button



Ballistics Mode (Sheet 3)

Blue Line: Up or Down Arrow
 Red Line: Left or Right Arrow
 Black Line: Select Button



Weather Mode (Sheet 4)

Blue Line: Up or Down Arrow
Red Line: Left or Right Arrow
Black Line: Select Button

All actions on this page are circular, meaning when you reach end of the list, it will circle back to initial menu item

Date & Time

Direction
(real-time)

Min/Max /Avg
Data Log
Graph

Wind Spd
(real-time)

Min/Max /Avg
Data Log
Graph

Crosswnd
(real-time)

Min/Max /Avg
Data Log
Graph

Headwnd
(real-time)

Min/Max /Avg
Data Log
Graph

Temperature
(real-time)

Min/Max /Avg
Data Log
Graph

Wind Chill
(real-time)

Min/Max /Avg
Data Log
Graph

Humidity
(real-time)

Min/Max /Avg
Data Log
Graph

Heat Index
(real-time)

Min/Max /Avg
Data Log
Graph

Dew Point
(real-time)

Min/Max /Avg
Data Log
Graph

Wet Bulb
(real-time)

Min/Max /Avg
Data Log
Graph

Station Pressure
(real-time)

Min/Max /Avg
Data Log
Graph

Baro Pressure
(real-time)

Min/Max /Avg
Data Log
Graph

Altitude
(real-time)

Min/Max /Avg
Data Log
Graph

Density Altitude
(real-time)

Min/Max /Avg
Data Log
Graph

User Screen 1

Row1
Row2
Row3

User Screen 2

Row1
Row2
Row3

User Screen 3

Row1
Row2
Row3