

Reference Guide Kestrel 5700

How Do I Find:

Please Note: A1st Quick Set will be missing if Accuracy 1st is turned off

Ballistics Side

- Set up a **Range Card** – TGT (↓) Wind (↓) Gun (↓) Enviro (↓) Range Card
- Set up a **Target Card** - TGT (↓) Wind (↓) Gun (↓) Enviro (↓) Range Card (↓)Target Card
- **Direction of Fire** – TGT (Enter) Target A (↓) A1st Quick Set (↓) TR (↓) DOF (Enter)
- **Accuracy 1st** – Mode (↓) Ballistics (↓) BlueTooth (↓) Data Port (↓) Memory Options (↓) Graph Scale (↓) Display (↓) System (Enter) Time & Date (↓) Compass Cal (↓) Accuracy 1st (→) on, off
- **Recalibrate My Compass** – Mode (↓) Ballistics (↓) BlueTooth (↓) Data Port (↓) Memory Options (↓) Graph Scale (↓) Display (↓) System (Enter) Time & Date (↓) Compass Cal (Enter)
- **DoF** - TGT (Enter)Target A (↓) TR (↓) DoF
- **Target Range Estimator** – TGT (↓) Target A (↓) A1st Quick Set (↓) TR (Enter)Unites (↓) Estimate – Enter size of target and Image
- **Target Speed Estimator** – TGT (↓) Target A (↓) A1st Quick Set (↓) TR (↓) DOF (↓) |deg (↓) |cos (↓) TS (Enter)TS Estimate – Enter range and movement
- **Wind Speed 1** – TGT (↓) Target A (↓) A1st Quick Set (↓) TR (↓) DOF (↓) |deg (↓) |cos (↓) TS (↓) WD (↓) WS1
- **Wind Direction** – TGT (↓) Wind (Enter) Target A (↓) WD (Enter)Wind Direction
- **Change MV from fps to m/s** - TGT (↓) Wind (↓) Gun (Enter) MV (Enter) Units (→) fps, m/s
- Access **Cal MV** - TGT (↓) Wind (↓) Gun (↓) MV (Enter) Units (↓) Cal MV (Enter)
- **Drag Model** - TGT (↓) Wind (↓) Gun (Enter) MV (↓) DM (Enter)
- **Ballistic Coefficient** - (↓) Wind (↓) Gun (Enter) MV (↓) DM (↓) BC (Enter)
- **Zero Range** - TGT (↓) Wind (↓) Gun (Enter) MV (↓) DM (↓) BC (↓) BW (↓) BD (↓) ZR (Enter)
- **Max PBR** - TGT (↓) Wind (↓) Gun (Enter) MV (↓) DM (↓) BC (↓) BW (↓) BD (↓) ZR (Enter) Zero Range (↓) Units (↓) Max PBR

- Change my **Bullet Height** - TGT (↓) Wind (↓) Gun (Enter) MV (↓) DM (↓) BC (↓) BW (↓) BD (↓) ZR (↓)BH (Enter) Units
- Change my **Zero Height** - TGT (↓) Wind (↓) Gun (Enter) MV (↓) DM (↓) BC (↓) BW (↓) BD (↓) ZR (↓)BH (↓) ZH (Enter) Units
- Change my **Cal DSF** - TGT (↓) Wind (↓) Gun (Enter) MV (↓) DM (↓) BC (↓) BW (↓) BD (↓) ZR (↓)BH (↓) ZH (↓) ZO (↓) RT (↓) Eunit (↓)Wunit (↓)Cal DSF (Enter) Range (↓) Drop (→) Units
- **View DSF** - TGT (↓) Wind (↓) Gun (Enter) MV (↓) DM (↓) BC (↓) BW (↓) BD (↓) ZR (↓)BH (↓) ZH (↓) ZO (↓) RT (↓) Eunit (↓)Wunit (↓)Cal DSF (↓)View DSF(Enter)
- **Delete my gun profile** - TGT (↓) Wind (↓) Gun (Enter) MV (↓) DM (↓) BC (↓) BW (↓) BD (↓) ZR (↓)BH (↓) ZH (↓) ZO (↓) RT (↓) Eunit (↓)Wunit (↓)Cal DSF (↓)View DSF (↓)Delete Gun
- **Update my Enviro** – TGT (↓) Wind (↓) Gun (↓) Enviro (Enter) Update
- **Turn off Spin Drift** – TGT (↓) Wind (↓) Gun (↓) Enviro (Enter) Update (↓) LAT (↓) Temp (↓) SP (↓) RH (↓) Dalt (↓) Spin Drift (→) on, off
- **Turn off Aero Jump** – TGT (↓) Wind (↓) Gun (↓) Enviro (Enter) Update (↓) LAT (↓) Temp (↓) SP (↓) RH (↓) Dalt (↓) Spin Drift (↓) Aero Jump (→) on, off
- **QkWind** – TGT (↓) Wind (↓) Gun (↓) Enviro (↓) Range Card (↓)Target Card (↓) Accuracy 1st (Enter) QkWind
- **WindDot** – TGT (↓) Wind (↓) Gun (↓) Enviro (↓) Range Card (↓)Target Card (↓) Accuracy 1st (Enter) QkWind (↓) WindDot
- **Spd Drp** – TGT (↓) Wind (↓) Gun (↓) Enviro (↓) Range Card (↓)Target Card (↓) Accuracy 1st (Enter) QkWind (↓) WindDot (↓) Spd Drp
- **Trace** – TGT (↓) Wind (↓) Gun (↓) Enviro (↓) Range Card (↓)Target Card (↓) Accuracy 1st (↓) Ballistics (Enter) Range (↓) Elv (↓) Wind 1 (↓) Wind 2 (↓) RTrms (↓) Rsubs (↓) Max o (↓) AerJ (↓) Vcor (↓) hCor (↓) SpnD (↓) Trce
- **Lead** – TGT (↓) Wind (↓) Gun (↓) Enviro (↓) Range Card (↓)Target Card (↓) Accuracy 1st (↓) Ballistics (Enter) Range (↓) Elv (↓) Wind 1 (↓) Wind 2 (↓) RTrms (↓) Rsubs (↓) Max o (↓) AerJ (↓) Vcor (↓) hCor (↓) SpnD (↓) Trce (↓) Drop (↓) Lead
- **Time of Flight** - TGT (↓) Wind (↓) Gun (↓) Enviro (↓) Range Card (↓)Target Card (↓) Accuracy 1st (↓) Ballistics (Enter) Range (↓) Elv (↓) Wind 1 (↓) Wind 2 (↓) RTrms (↓) Rsubs (↓) Max o (↓) AerJ (↓) Vcor (↓) hCor (↓) SpnD (↓) Trce (↓) Drop (↓) Lead (↓) ToF

- **Remaining Velocity** – TGT (↓) Wind (↓) Gun (↓) Enviro (↓) Range Card (↓)Target Card (↓) Accuracy 1st (↓) Ballistics (Enter) Range (↓) Elv (↓) Wind 1 (↓) Wind 2 (↓) RTrms (↓) Rsubs (↓) Max o (↓) AerJ (↓) Vcor (↓) hCor (↓) SpnD (↓) Trce (↓) Drop (↓) Lead (↓) ToF (↓) RemV
- **Remaining Energy** – TGT (↓) Wind (↓) Gun (↓) Enviro (↓) Range Card (↓)Target Card (↓) Accuracy 1st (↓) Ballistics (Enter) Range (↓) Elv (↓) Wind 1 (↓) Wind 2 (↓) RTrms (↓) Rsubs (↓) Max o (↓) AerJ (↓) Vcor (↓) hCor (↓) SpnD (↓) Trce (↓) Drop (↓) Lead (↓) ToF (↓) RemV (↓) RemE
- **Add a New Gun** - TGT (↓) Wind (↓) Gun (↓) Enviro (↓) Range Card (↓)Target Card (↓) Accuracy 1st (↓) Ballistics (↓)Manage Guns (Enter) New Gun

How Do I Find:

Weather Side

- **Wind Speed** – Mode (→) Weather (Enter) Direction deg (↓) Wind Spd
- **Cross Wind** – Mode (→) Weather (Enter) Direction deg (↓) Wind Spd (↓) CrossWnd
- **Head Wind** – Mode (→) Weather (Enter) Direction deg (↓) Wind Spd (↓) CrossWnd (↓) HeadWND
- **Temp** – Mode (→) Weather (Enter) Direction deg (↓) Wind Spd (↓) CrossWnd (↓) HeadWND (↓) Temp
- **CHILL** – Mode (→) Weather (Enter) Direction deg (↓) Wind Spd (↓) CrossWnd (↓) HeadWND (↓) Temp (↓) CHILL
- **Humidity %** – Mode (→) Weather (Enter) Direction deg (↓) Wind Spd (↓) CrossWnd (↓) HeadWND (↓) Temp (↓) CHILL (↓) HUMIDITY%
- **Heat index** – Mode (→) Weather (Enter) Direction deg (↓) Wind Spd (↓) CrossWnd (↓) HeadWND (↓) Temp (↓) CHILL (↓) HUMIDITY% (↓) Heat Index
- **Dew Point** – Mode (→) Weather (Enter) Direction deg (↓) Wind Spd (↓) CrossWnd (↓) HeadWND (↓) Temp (↓) CHILL (↓) HUMIDITY% (↓) Dew Point
- **Pressure inHG** – Mode (→) Weather (Enter) Direction deg (↓) Wind Spd (↓) CrossWnd (↓) HeadWND (↓) Temp (↓) CHILL (↓) HUMIDITY% (↓) Dew Point (↓) Wet Bulb (↓) Pressure inHG
- **BARO inHG** – Mode (→) Weather (Enter) Direction deg (↓) Wind Spd (↓) CrossWnd (↓) HeadWND (↓) Temp (↓) CHILL (↓) HUMIDITY% (↓) Dew Point (↓) Wet Bulb (↓) Pressure inHG (↓) BARO inHg
- **Altitude** – Mode (→) Weather (Enter) Direction deg (↓) Wind Spd (↓) CrossWnd (↓) HeadWND (↓) Temp (↓) CHILL (↓) HUMIDITY% (↓) Dew Point (↓) Wet Bulb (↓) Pressure inHG (↓) BARO inHg (↓) Altitude

- **Dens Alt** – Mode (→) Weather (Enter) Direction deg (↓) Wind Spd (↓) CrossWnd (↓) HeadWND (↓) Temp (↓) CHILL (↓) HUMIDITY% (↓) Dew Point (↓) Wet Bulb (↓) Pressure inHG (↓) BARO inHg – Altitude (↓) Dens ALT


How Do I Find:

System Settings


- **BlueTooth** – Mode (↓) Ballistics, Weather, Easy (↓) Bluetooth
- **Data Port** – Mode (↓) Ballistics, Weather, Easy (↓) Bluetooth (↓) Data Port
- **Memory Options** – Mode (↓) Ballistics, Weather, Easy (↓) Bluetooth (↓) Data Port (↓) Memory Options
- **Graph Scale** – Mode (↓) Ballistics, Weather, Easy (↓) Bluetooth (↓) Data Port (↓) Memory Options
- **Auto Shtdown** – Mode (↓) Ballistics, Weather, Easy (↓) Bluetooth (↓) Data Port (↓) Memory Options (↓) Graph Scale (↓) Display (→) Auto Shtdwn
- **Contrast** – Mode (↓) Ballistics, Weather, Easy (↓) Bluetooth (↓) Data Port (↓) Memory Options – Graph Scale (↓) Display (→) Auto Shtdwn (↓) Contrast
- **BackLight** – Mode (↓) Ballistics, Weather, Easy (↓) Bluetooth (↓) Data Port (↓) Memory Options (↓) Graph Scale (↓) Display (→) Auto Shtdwn (↓) Contrast (↓) Back Light
- **Time & Date** – Mode (↓) Ballistics, Weather, Easy (↓) Bluetooth (↓) Data Port (↓) Memory Options (↓) Graph Scale (↓) System (→) Time & Date
- **Measurements** – Mode (↓) Ballistics, Weather, Easy (↓) Bluetooth (↓) Data Port (↓) Memory Options (↓) Graph Scale (↓) System (→) Time & Date (↓) Compass Cal (↓) Accuracy 1st (↓) Measurement
- **Global Units** – Mode (↓) Ballistics, Weather, Easy (↓) Bluetooth (↓) Data Port (↓) Memory Options (↓) Graph Scale (↓) System (→) Time & Date (↓) Compass Cal (↓) Accuracy 1st (↓) Measurement (↓) Units (→) Global (→) Global Units

Home Page Layout


Kestrel 5700 Elite
Software Ver. 1.49




Target Submenu




Wind Submenu




Gun Submenu




Enviro Submenu




k # Submenu







Accuracy 1st Submenu




Ballistics Submenu




Manage Guns Submenu



Weather Side



Main Menu



Kestrel 5700 Elite
Software Ver. 1.49

Kestrel 5700 Elite
Software Ver. 1.49

Kestrel 5700 Elite
Software Ver. 1.49